


Large print



L30 Indicates reset lights up shortly at high voltage

L31 Indicates low voltage

L44 Indicates communication to monitor. Flashes normally weakly

L63 Indicates tension to the card (the electronic part)

L64 Indicates tension to the card (the power section)

F1 Fuse The electronic part
F2 Fuse The power section

J142 Programming terminal
Jumper pos.1 if partly shut down used as main shut down. Jumper pos.2 is comp valves are used.

Other switches and LEDs, see the connection instruction 12017401.wps.